

11 PC Connectivity

The Hema Navigator 5" can be connected to a PC for the following purposes:

- Accessing the contents of Navigator's MicroSD Card.
- Using Route 66 Sync to purchase and activate products through the Route 66 Store such as extra mapping and functionality.

NOTE: The Hema Navigator 5" is only compatible with Microsoft Windows - Windows 7, Vista and XP.

WARNING: Changing the content of the Resident Flash (on-board memory) inadvertently may render the device inoperable. Do not do so unless instructed by the Hema Navigator Support Team.

When the USB cable, supplied with the Navigator is plugged into the PC and the mini USB connector inserted into the device, the following three icons will be displayed:



USB Connection Mode

This will display the contents of the Resident Flash (on-board memory) and MicroSD card as Removable Disks in Windows Explorer on your computer. Windows will automatically assign drive letters to these disks once they are detected.

Note: The device will not charge using this mode



Windows PC Connection Mode

Route 66 requires this mode of connectivity in conjunction with its Route 66 Sync application.

To facilitate this connection one of the following applications need to be installed on your computer:

- *ActiveSync – Windows XP*
- *Windows Mobile Device Centre – Windows 7, Vista*

These applications are available for free download from the Microsoft Download Centre at <http://download.microsoft.com>

This mode will also display all of the contents of the device in Windows Explorer, including the Resident Flash (on-board memory).

Note: The device will not charge using this mode



Power Connection Mode

This mode will charge the Navigator device using the USB port of the PC as the charging source. This mode provides no connectivity.